INSTALLATION INSTRUCTIONS

Product name:

VILLA Round Down Light

Model No.:

VRA050 VRA075 VRA095 VRA120 VRF050 VRF075 VRF095 VRF120









Please read these instructions carefully before commencing installation and retain for future reference. If any problem, please consult qualified electricians to get some help. These products must not be modified. If any modification is made it may invalidate the warranty and may render the product un-safe. All electrical installations must be carried out according to current IEE Wiring Regulations.

IMPORTANT SAFETY NOTES

- 1. Make sure all main power are disconnected before commencing installation or lamp change and (if a fuse box is used) remove the appropriate circuit fuse to avoid accidental switching on of the mains supply.
- 2. Connect to a 220V-240V supply in accordance with IEE regulations.
- 3. Make sure all connections are tight with no loose strands.
- 4. Ensure fire regulations are not breached when fitting your lights.
- 5. If you are in any doubt regarding these instructions, consult a qualified electrician.


WARNING:


- 1. For indoor use only
- 2. Please ensure that the packaging is disposed of in a safe environment.
- 3. If cable is defected, do not use or exchange the cable.
- 4. We do recommend that a qualified electrician should be used to install the products.
- 5. Do not look at the lighted lamp directly.

INSTALLATION METHOD ONE (Applicable to cut out size of Ф50mm, Ф75mm) Open a hole in the ceiling, suitable for thickness Lightly press the plastic clasp on the both side of Press the two clips with your hands to install Connect the power line to the mains, connect the the lamp body, and use a screwdriver to separate the mounting ring into the ceiling hole re line to "I " and connect the neutral line to "N" Put the driver into the ceiling. Install the lamp body into the mounting ring Align the locating post of reflector with the 8 Installation complete, power on make sure the plastic clasp be clipped into locating slot and put it into the lamp body the mounting ring and confirm it's well confirm it's well installed.

(2) INSTALLATION METHOD TWO(Applicable to cut out size of Ф50mm, Ф75mm)











(£ ((()

Fuyong, Bao'an District, Shenzhen, China 518103.


INSTALLATION INSTRUCTIONS

3 INSTALLATION METHOD THREE (Applicable to cut out size of Φ95mm, Φ120mm)






















4 INSTALLATION METHOD FORE (Applicable to cut out size of Φ95mm,Φ120mm)











(5) INSTALLATION METHOD FIVE (Applicable to cut out size of Φ95mm, Φ120mm)















Fuyong, Bao'an District, Shenzhen, China 518103.



